



23 Exhibition Drive, Malaga Western Australia

Monday - Friday 7am-5pm + Sat 8am-4pm

Sales Centre for Sales, Advice + Orders

T +61 8 9209 7400

hello@beyondtools.com

SCISSORS SHARPENING JIG SVX-150 BY TORMEK



SKU	Option	Part #	Price
3955		SVX-150	\$115

Model	
Type	Sharpening Jig
SKU	3955
Part Number	SVX-150
Barcode	7392485002055
Brand	Tormek
Packaging + Shipping	
Shipping Weight (Gross)	1.48 kg



Give your scissors a bite on the Tormek with the SVX-150 jig for scissors. It fits all sorts of scissors from household scissors to heavy garden shears. You can also sharpen pinking scissors that make zigzag cuts in cloth as well as portable electrical hand planer blades.

The scissors are mounted in a holder, which supports freely on a support plate. The grinding angle can be set so that you exactly replicate the existing edge angle.

One of the scissor blades, sometimes both of them, often have a slight convex shape. With the Tormek jig design, you follow the individual shape of each blade so that the sharpening runs smoothly.

The rotation of the stone presses the scissor blade towards the support plate, so you can concentrate on moving the scissors across the stone.

Features

Features

Sharpens Scissors and Shears

The Individual Convex Shape of the Scissors can be Followed

Can Also be used for Portable Electric Hand Planer Blades

The Jig has Two Clamps, but Usually Only the Right Clamp is Needed

Use Both Clamps for Large Scissors and Garden Shears

Full Manufacturer Warranty