



23 Exhibition Drive, Malaga Western Australia

Monday - Friday 7am-5pm + Sat 8am-4pm

Sales Centre for Sales, Advice + Orders

T +61 8 9209 7400

hello@beyondtools.com

PLAY KITCHEN HUTCH, WOODEN TOY PLAN & PATTERN



SKU	Option	Part #	Price
9000040		WPH	\$22

Model	
Type	Carpentry & Woodworking Project Plan
SKU	9000040
Part Number	WPH
Barcode	9345281001461
Brand	Enjoy Making Wooden Toys
Packaging + Shipping	
Shipping Weight (Gross)	0.55 kg

Create your own Wooden Toy Plans with Wood Toy Plans & Pattern Kits with Step by Step Instructions These plans are ideal for beginner woodworkers:-

Follow Plans, Patterns

Mark onto Material

Cut out from Timber

Glue / Screw Together

Stain / Paint

Please note each plan requires different equipment:

Basic Tools: (Minimum)

Electric Hand Drill/Screw driver

Hand Saw

Sand Paper

Band saw or Jig saw

Recommended Tools

Electric Saw

Electric Disk and/or Belt Sander

Router

Band Saw



23 Exhibition Drive, Malaga Western Australia

Monday - Friday 7am-5pm + Sat 8am-4pm

Sales Centre for Sales, Advice + Orders

T +61 8 9209 7400

hello@beyondtools.com

Images shown are only indicative of the final Wood Toy, as it depends on your choice of timber / painting to suit your preference.