

## 23 Exhibition Drive, Malaga Western Australia

Monday - Friday 7am-5pm + Sat 8am-4pm

Sales Centre for Sales, Advice + Orders T +61 8 9209 7400 hello@beyondtools.com

## 200MM DIAMOND WHEEL COARSE 360G SUIT T-4 DC-200 BY TORMEK



Features: • The DC-200 Diamond Wheel Coarse is designed to provide effective sharpening and rapid repair of a dull or damaged edge. • The diamond wheel has a grit size of 360 for fast steel removal and is particularly useful for tool shaping. • Fast steel removal to repair or reshape edges. • Constant shape, always maintains the same diameter. â€ ¢ Sharpens all types of steel and ceramic. • Allows sharpening on the side of the grinding wheel to get a completely flat bevel. • Exceptional durability with diamond, the world's hardest abrasive. • A grinding wheel for all materials • With this diamond wheel, you can sharpen nearly any type of material, including steel, ceramic and carbide, • DC-200 Diamond Wheel Coarse fits Tormek T-4 Original, Tormek T-4 Bushcraft, Tormek T-3 and earlier models with a 200 mm diameter grinding wheel. Simplifies repeat sharpening • All of Tormek's diamond grinding wheels have exceptional durability with a constant removal rate and shape, which means that they always stay round and flat with a full-size diameter. • Users who often sharpen the same tool benefit greatly from this, as it simplifies both setting and grinding. Get a completely flat bevel • The constant shape makes it possible to grind either on the side of the wheel or on its upper surface. • Side grinding is perfect for smaller tools such as knives, chisels, carving gouges and v-tools. • The result is an edge with a completely flat bevel, instead of a slight hollow grind. • For sharpening on the side of the diamond wheels, we recommend using the MB-100 Multi Base together with the jig designed for your specific tool. • Both the base and the jigs give you support and control throughout the sharpening process. Rust protection for increased service life • All diamond wheels are supplied with 150 ml of ACC-150 Anti-Corrosion Concentrate. • Always add the concentrate to the water when sharpening with water to prevent rust on the grinding wheel. • Add 10 ml of concentrate to 250 ml water (~4 %). We recommend always using water when sharpening diamond wheels, as it both prolongs the life of the wheel and provides a smoother grinding surface. • It is also possible to sharpen without water.



SKU	Option	Part #	Price
8730124		DC-200	\$405

Model	
Туре	Water Cooled / Wet Stone Sharpener Accessory
SKU	8730124
Part Number	DC-200
Barcode	7392485006329
Brand	Tormek
Technical - Main	
Diameter	200mm
Packaging + Shipping	
Shipping Weight (Gross)	1.48 kg